

一、下载安装APP

扫描下方二维码或前往各大应用商店搜索“i-Cam+”下载安装。



二、注册登录账号

1. 打开APP点击注册账号，输入手机号或邮箱地址并点击“注册”按钮。
2. 输入验证码并点击“下一步”。
3. 设置登录密码。
4. 输入注册所用的手机号或邮箱地址并输入验证码。

三、设备连接

1. 点击“添加家庭或设备安装位置”按钮。
2. 输入您的家庭名称。
3. 输入国家或地区、省份等必填内容。
4. 点击添加智能设备。

四、设备使用说明

1. 点击“添加家庭或设备安装位置”按钮。
2. 推送开关，点击可关闭推送。
3. 设置按钮，点击可分享权限、选择开通云服务、删除设备。
4. 点击进入预览界面。
5. 点击“添加智能设备”按钮。
6. 点击设置按钮进入设备设置、基本信息界面。
7. 设备开关按钮。
8. 实时录像按钮。
9. TF与“云存储”切换按钮。
10. 实时录像按钮。
11. 麦克风按钮。

五、注意事项

- 设备属于低功耗智能产品，不支持APP长时间运行，PIR人体检测唤醒，按唤醒后每次唤醒后工作一段时间后会自动进入休眠状态。设备的工作时间可以在APP简单中设置。
- 设备属于低功耗智能产品，不支持APP长时间运行，PIR人体检测唤醒，按唤醒后每次唤醒后工作一段时间后会自动进入休眠状态。设备的工作时间可以在APP简单中设置。
- 设备属于低功耗智能产品，不支持APP长时间运行，PIR人体检测唤醒，按唤醒后每次唤醒后工作一段时间后会自动进入休眠状态。设备的工作时间可以在APP简单中设置。
- 设备属于低功耗智能产品，不支持APP长时间运行，PIR人体检测唤醒，按唤醒后每次唤醒后工作一段时间后会自动进入休眠状态。设备的工作时间可以在APP简单中设置。
- 设备属于低功耗智能产品，不支持APP长时间运行，PIR人体检测唤醒，按唤醒后每次唤醒后工作一段时间后会自动进入休眠状态。设备的工作时间可以在APP简单中设置。


1. APP INSTALLATION

(1.) Scan the following QR codes or search for "i-Cam+" from the AppStore (for iOS devices) or Google Play Store (for Android smartphones) to download and install the app.




2. APP REGISTRATION

(1.) Open the app then input your E-mail address then press "Register".
(2.) Set the login password and confirm the login password.



3. WI-FI CONNECTION

(1.) Press 'Add Family' then set the room or position as per reminders.
(2.) Enter your family name and then press 'Next'.
(3.) Input the necessary information just like Country, Province, then press 'Done'.
(4.) Press 'Add a device' to add a smart device.
(5.) Connect the device with power supply, and make sure your mobile phone is connected to an available Wi-Fi. Then press 'Setup device'.
(6.) After the power on the device, wait for the device blue LED are blinking. Which means your device in pairing mode.



(7.) If the device blue are not blinking, please press the power/call key to wake up the device first, then hold and press the RESET button until the blue indicator to light up and then release. The device will reboot and enter the pairing state.

(8.) Set the device name and select the device location before setup.

(9.) The app will input the Wi-Fi name and the Wi-Fi Password. Then you can choose the 'QR code configuration' or 'Sound wave configuration'.


(10.) QR code configuration: Select the QR code configuration then the mobile phone display a QR code. Use the device to scan to the QR code 10cm away from the mobile phone.

(11.) The device will enter to the device list automatically. Setup success! The device is ready to use.

(12.) Notes about PIR detection: "User can change the PIR detection sensitivity in device settings, we recommend to set sensitivity at 'Disabled' or 'Low' to reduce false alert and save the battery power in noisy environments." "Disabled: disabled PIR detection." "Low: delay 7 seconds. PIR detects a moving." "Medium: delay 5 seconds. PIR detects a moving." "High: delay 3 seconds. PIR detects a moving."


4. USING THE APP

Enter to select your family or smart device location.
Turn on/off the push notification.
Settings: Sharing, Cloud storage, Delete the device.
Press to enter the preview section.
Press to add a smart device.
Account and value-added account management.
Smart device basic settings: Could set "Storage management, Flip screen, Environmental model, PIR detection, Sleep time, Power frequency, LED indicator, Device name". Could check the information of "Device name, Device ID, Model, FW version, Manufacturer, Check for the FW updates."
Turn on/off the speaker
Screenshot
Playback switch "Micro SD memory" and "Cloud storage".
Take a video for the live view
Microphone - Speak to the smart device side.



5. SPECIAL NOTES!

(1.) The device is equipped with a rechargeable lithium battery. The battery life will be affected by the device wake-up time and the number of wake-ups. Therefore, the PIR sensor alarm detection function is used in a environment with a lot of people. It is recommended to turn off or set the device to low sensitivity to reduce device wake-up and call times extend battery life. When the battery is low, please charge the battery immediately.
(2.) Keep the device in range of your router. Make sure the device is placed close to the Wi-Fi router. If there has to be thick or insulated objects between the device and the Wi-Fi router, which may lead to weak Wi-Fi signal, please make sure the Wi-Fi signal is in good level before you start using the device.
(3.) It is a delicately device with low power consumption design. Everytime the device is awakened and will work for few seconds. After that, the device will enter standby mode to save power. You can set the work time in the app settings.
(4.) Because the mainland China does not receive Google's system push messages, you need to open the app's self-starting function in your phone to receive push messages.
(5.) This device provides one month of free cloud storage and face recognition services. If you need to continue using value-added services after the trial period expires, you need to purchase them in the app.





i-Cam+

User Guide

The user guide is for reference only. Screen shots displayed in this user's guide or those currently featured in your app as frequent updates and improvements.